

EVAPORATOR
 EVAPORATOR DRAIN HOSE
 EVAPORATOR DRAIN ELBOW-UPP
 EVAPORATOR DRAIN ELBOW-LOW
 EVAPORATOR DRAIN PAN
 EVAP AIR GUIDE RIGHT
 EVAPORATOR DRAIN INSUL
 EVAP AIR GUIDE MID
 EVAP FAN MOTOR ASSY
 EVAP AIR GUIDE LEFT
 BRACKET-DRAIN
 ASSY LAMP LED
 COVER EVA
 EVA COVER SUPPORT LF

U-COVER BRACKET

ASSY HINGE TOP RH
 ASSY HINGE TOP LF
 SHAFT TOP HINGE AS
 PIN TENSION

ASSY GRILL TOP
 SWITCH DOOR
 SWITCH POWER
 DOOR LOCKING ASSY
 STOPPER HINGE LF
 ASSY HINGE BOTTOM LF

ASSY DOOR LF
 STOPPER DOOR LF

PCB DISPLAY
 COVER DISPLAY
 INLAY CONTROL

GASKET DOOR
 ASSY DOOR RH
 STOPPER DOOR RH

EVA COVER SUPPORT RH
 COVER LAMP

EVAPORATOR FAN MOTOR GUARD

STOPPER HINGE RH
 ASSY HINGE BOTTOM RH

CASTER 4"(NO BRAKE)

CASTER 4"(BRAKE)



KTSR-3