

CHANGING PARAMETERS ENTER MANAGER SECURITY CODE: 1001



CHANGING PARAMETERS IS REQUIRED TO CHANGE ALL CODES BELOW


CHEMICAL PUMP enable or disable the detergent pump or rinse aid pump.




WASH CYCLE allows the customization of total run time.




LOW TEMP ALARMS for hot machines only: (parameter) enables or disables alert indicating that the final rinse temperature has been below the minimum temperature for a period of time.




WASH ARM ALARM enables or disables an alarm that alerts the operator that the wash arms may be clogged or blocked.




DELIME enables or disables the delime reminder alert.



TEMPERATURE UNITS allows the choice of Fahrenheit or Celsius.



POTABLE RINSE for cold machines only enables or disables the potable water rinse option.



DIRTY WATER INDICATOR disables or gives a choice of how many cycles the machine will run between dirty water alert and refresh cycles.

▼ → until DIRTY WATER INDICATOR → ENT → ▼ to Disable, 20 cycles, 40 cycles, or 60 cycles → ENT OR ▼ → until EXIT MENU → ENT → ▼ until EXIT → ENT

ENERGY SAVER MODE disables or gives choice of how many hours before the unit will stay on before entering energy saving mode.

▼ → until ENERGY SAVING MODE → ENT → ▼ to Disabled, 1 Hour, 2 Hours, or 3 Hours → ENT OR ▼ → until EXIT MENU → ENT → ▼ until EXIT → ENT

ADD CHEMICAL ALERT enable or disable the audio alert of missing chemicals.

▼ → until ADD CHEM AUDIO ALERT → ENT → ▼ to enable or disable → ENT OR ▼ → until EXIT MENU → ENT → ▼ until EXIT → ENT

END CYCLE AUDIO ALERT enable or disable the unit creating an audio alert at the end of each wash cycle.

▼ → until END CYCLE AUDIO ALERT → ENT → ▼ to enable or disable → ENT OR ▼ → until EXIT MENU → ENT → ▼ until EXIT → ENT

LANGUAGE allows the choice of English, French or Spanish language.

▼ → until LANGUAGE → ENT → ▼ to English, French or Spanish → ENT OR ▼ → until EXIT MENU → ENT → ▼ until EXIT → ENT

advansys BUTTON allows the customization of the **advansys** button to be used for a variety of options.

▼ → until **advansys** BUTTON → ENT → ▼ to: Clean Sump, One Light Wash, One Normal Wash, One Heavy Wash (LXe only), Run Delime Cycle, or Energy Saver → ENT OR ▼ → until EXIT MENU → ENT → ▼ until EXIT → ENT

EXIT MENU TO MAIN MANAGER MENU

→ ▼ until EXIT MENU → ENT

DELIME NOW allows for a single delime cycle to be run from the menu at anytime.

Note: this operation takes 20-45 minutes depending on conditions.

▼ → until DELIME NOW → ENT → ▼ to YES or NO → ENT (this will exit menu)

